


# Outdoor Sun Shade ASSEMBLY, INSTALLATION, CARE and USE INSTRUCTIONS

### IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

English speaking customer service representatives are available Monday through Friday, from 7am - 4pm (MST) at 303.652.6164. Visit our website www.KoolSpot.net for video instructions. We recommend two (2) people install this shade. This shade is designed for outdoor use. A power drill, tape measure, leveling device, and Phillips screwdriver bit are recommended for installation (not included). Please lay out and take inventory of all parts prior to assembly. Please give us a call if you are missing any parts. Read instructions in their entirety prior to beginning assembly and installation. Note: Valance (A) must be installed into wood studs. If woods studs are not available, anchoring hardware must be used (not included).







# STEP 1: Remove Protective Film from Valance

Remove and discard the anti-scratch film that covers the Valance (A).

# STEP 2: Install Ring

Using the Ring Screw (N) and 5mm Lock Washer (P) provided in the pole package, attach the Ring (M) to the Crank Mechanism (H) (Fig. 1).

# STEP 3: Determine Your Installation Type

Determine your type of installation. Your sun shade can be hung from a wall or a ceiling. Figure 2 illustrates a wall installation, Figure 3 illustrates a ceiling installation.

# STEP 4: Install Valance Brackets (read entire step before install)

Your shade includes three (3) Valance Brackets (L), you must install at least two (2) of them. Install one (1) Valance Bracket (L) near each end of the shade. Note: the Valance Brackets (L) cannot be installed on the extreme edges of the shade, you will need to allow at least 2 inches (5 cm) at the ends of each side. We recommend installing the Valance Brackets (L) on the closest stud to each end of the shade, remembering to allow at least 2 inches (5 cm) from each end. If wood studs are not available, you will need to use anchors (not included).

If you are installing the third Valance Bracket (L) (recommended), we suggest installing it on a wood stud near the center of the shade. It needs to be aligned with the two (2) end Valance Brackets (L). If wood studs are not available, you will need to use anchors (not included). Visit your local hardware store for more information.

Your shade includes a paper template to help align your pilot holes. Use of the template is optional, but recommended. To use the template, temporarily adhere to your surface. Make sure the template is flat, level and unwrinkled before adhering it to your surface. Remove the template before you install your Valance Brackets (L).

Important note: your shade will not install correctly unless your Valance Brackets (L) are perfectly aligned with each other. We recommend using a laser level (not included) to align the screw holes.

### WALL INSTALLATION

For wall installations, allow at least 1 inch (2.5 cm) above the Valance Bracket (L) to allow the Valance (A) to hook onto the Valance Bracket (L) (only if there is a ceiling that overhangs the shade) (Fig. 4).

For a wall installation, make sure the plastic tabs on your Valance Brackets (L) are pointing towards the ground (see Fig. 5). Use the Bracket Screws (K) to install the Valance Brackets (L).

### **CEILING INSTALLATION**

For ceiling installations, allow at least 1 inch (2.5 cm) behind the Valance Bracket (L) to allow the Valance (A) to hook onto the Valance Bracket (L) (only if there is a wall/window behind the shade) (Fig. 6).

For ceiling installation, make sure the plastic tabs on your Valance Brackets (L) are pointing out, towards you (Fig. 7). Use the Bracket Screws (K) to install these Valance Brackets (L).







Fig. 3








Fig. 6



Fig. 7

# STEP 5: Install the Shade

For wall installations, first hook the back of the Valance (A) on the top of Valance Brackets (L) (Fig. 8), then rotate the shade down and click it into place (Fig. 9).

Note: you may need to push up on the spring-loaded plastic tabs on the Valance Brackets (L) to help the shade click it into place.

WALL INSTALLATION

For ceiling installations, first hook the back of the Valance (A) on the back of the Valance Brackets (L) (Fig. 10), then rotate the Valance (A) upwards and click it into place (Fig. 11).

Note: you may need to push inwards on the spring-loaded plastic tabs on the Valance Brackets (L) to help the shade click it into place.



# STEP 6: Assemble Pole

To assemble your pole, slide the Pole-Mid Piece (S) onto the Pole-Long Piece (T), making sure the holes are pointing towards the handle (Fig. 12). Then, slide the Pole-Handle Piece (R) into the Pole-Mid Piece (S).

Insert the Pole Screws (Q) into the Pole-Mid Piece (S) and completely tighten (these screws are located in your pole package). Note: Not all of the Pole-Long Piece (T) is shown in Figure 12.

To use the pole simply insert the hook into the Ring (M) and turn the Pole-Handle Piece (R).





Fig. 12

# Install Bungee System (optional step)

The shade includes two (2) Bungee Systems (J) to secure the bottom of both sides of your shade. To install the Bungee System (J), start by feeding the Bungee through the Bottom Tube Plugs (C) located at each end of your Bottom Tube (Fig. 13). Determine your desired location for your Hook and use a drill to install the Hook into a wall/post (Fig. 14). To use the Bungee, insert the Bungee into the Hook (Fig. 15). To prevent fabric stretching/damage, Hooks should be installed directly underneath the Bottom Tube Plugs and so there is equal tension on each bungee.

Important: Your shade should be rolled up during windy conditions. The Bungee System (J) is only effective in light wind. When using your shade, we recommend leaving at least one (1) roll of fabric wrapped around the top tube.



# Additional Optional Steps

## REVERSING THE ROLL DIRECTION OF YOUR FABRIC

The default fabric roll direction of your shade is "reverse". That is, the fabric rolls from the back side of the top tube. If you want the fabric to roll towards the front of your shade, simply roll your shade down until the fabric begins to roll itself back up, towards the Valance (A). Note: if you reverse the roll direction of your fabric, you will need to move your Ring (M) so it does not interfere with the fabric. Please visit "www.KoolSpot.net/video-help" for instructions on this process.

### MOVING THE RING FROM THE FRONT TO THE BACK OF THE SHADE

The default placement for your Ring (M) is in the front of your shade. That is, the Ring (M) is placed near the front of the Valance (A). If you want to move your Ring (M) to the back of the Valance (A), please contact us for instructions on this process. Note: if you move the Ring (M) from the front to the back of your Valance (A), you will also need to reverse the roll direction of your fabric. Please visit "www.KoolSpot.net/video-help" for instructions on this process.

### MOVING THE RING FROM THE RIGHT TO LEFT SIDE OF THE SHADE

The default location for your Ring (M) is on the right side of your shade. If you want to move the Ring (M) to the left side of your shade, please visit "www.KoolSpot.net/video-help" for instructions on this process.

## Care & Maintenance

To clean your shade, simply rinse with water and soap, scrub with a soft brush. Note: Using bleach or an abrasive cleaner will void your warranty. Roll the shade down to air dry. Your shade should be rolled up during windy conditions. To prolong the life of your shade, we recommend leaving one (1) roll of fabric wrapped around the top tube when using your shade.